

Patch Kit - User Manual

FOR MODELS

Lever Kit

Alloy Kit

Metal Kit

Smart Kit

Classic Kit

APPLYING GLUELESS PATCHES

1. Locate puncture hole in tube
2. Clean and roughen area around hole with supplied scuffer
3. Peel off backing and apply over hole
*Avoid touching glue side
4. Press and hold patch firmly for 30 seconds
5. Reinstall tube and inflate
6. Finish your ride.

APPLYING GLUE PATCHES

1. Locate puncture hole in tube
2. Clean and roughen area around hole with supplied scuffer
3. Apply glue and wait approximately 2 minutes or until glue is tacky.
4. Press and hold patch firmly for 30 seconds
5. Reinstall tube and inflate
6. Finish your ride.

TIRE BOOT

- In the occurrence of a rip, slice, or tear in your tire:
This boot can be used as a patch between your tire and tube to help prevent your tube from blowing out of the damaged tire. Simply remove the clear film to expose glue and place boot over rip. Once you've reached your destination immediately replace your tire with a new one.

LEZYNE

Engineered Design

www.lezyne.com