


English Quick Start


Ride screen button functions:



Menu & pause screen button functions:




MICRO USB



USB SEAL



COMPUTER MOUNT



Welcome.

Fully charge your Lezyne GPS with the included USB cable plugged into a computer or wall charger before using it the first time. It is also recommended to visit lezyne.com/gpsroot and update your GPS device to the latest software to maintain the best compatibility with your phone and sensors.

Go ride

Turn on your Lezyne GPS by holding the top left button. **Wait for a GPS signal to register.** Start recording by pressing the bottom right button **▶** and enjoy your ride.

Page through other data fields while recording by pressing the top right button **▶**.

Enter the pause menu by holding the bottom right button **▶**. To continue recording, select the option RESUME by pressing the bottom left button **ENTER** or scroll through other options by pressing one of the top or bottom right buttons.

Select the option END to go to the file menu. Now choose to SAVE or DISCARD your file.

Analyze

Connect your Lezyne GPS to a computer via Micro USB cable. Within the Lezyne GPS folder find your .FIT ride files in the Activities folder to upload, view, and share for free at: www.lezyne.com/gpsroot

More Info

For instructions and safety information, see the User Guide. Download the .PDF at: www.lezyne.com/support-downloads.php

Menu Outline:

- Alert
- Ride Distance
- Ride Time
- Calories
- Min HR (Heart Rate)
- Max HR (Heart Rate)
- Speaker
- Time Out
- Auto
 - Scroll
 - Pause
 - Lap
 - Light
- Bike
 - Wheel Circ.
 - Bike Weight
- Personal
 - Sport Type
 - Language¹
 - Age¹
 - Weight¹
 - Height¹
 - Gender¹
- Records
 - Erase All
 - Erase Oldest
 - Memory Free
 - Reset Trip 1
 - Reset Trip 2
 - Reset Odo (Odometer)
- Phone
 - iPhone
 - Android
- Navigation
 - Rerouting
- Sensors
 - Heart Rate
 - Speed
 - Cadence
 - Speed & Cadence
 - Power
 - Shifting
- Screen
 - Data Pages
 - ▼ No. Of Pages
 - ▼ No. Of Fields
 - ▼ Fields
- Unit Format
- Backlight
- Contrast
- Notifications
- Time
 - Time Format
 - Time Zone¹
 - Daylight Saving¹
- Info
 - Device
 - Firmware
 - Gps Mode
 - Satellites
 - HDOP
 - VDOP
 - Battery
 - FCC ID
 - IC
 - RCM
 - Bluetooth LE
 - Ant+²


1. Required Fields
2. Ant+ is only supported on ENHANCED GPS units.

퀵스타트 가이드


주행 화면 시 버튼 기능




메뉴 & 멈춤 화면에서의 버튼 기능



MICRO USB



USB 보호 마개



마운트에 기기 장착



제품 처음 사용시

제품 최초 구입 시 사용전에 사용자의 GPS 기기를 동봉된 USB 케이블을 컴퓨터 포트 또는 아답터에 연결하여 완충 시까지 충전합니다. 또한, 스마트폰과 센서의 원활한 연결을 위하여 lezyne.com/gpsroot에 방문하여 사용자의 GPS 기기를 최신 소프트웨어로 업데이트할 것을 권장해드립니다.

주행 시작

상단 왼쪽의 버튼을 길게 눌러 리자인 GPS 전원을 켭니다. GPS 신호를 잡을 때까지 몇 분정도 기다립니다. 오른쪽 하단 **▶** 버튼을 눌러 주행 기록을 시작합니다.

주행 기록 시에 다양한 주행 정보를 보고싶다면 오른쪽 상단 **▶** 버튼을 눌러 페이지를 스크롤할 수 있습니다. 기록 중 멈춤은 오른쪽 하단 **▶** 버튼을 길게 눌러 일시 중지할 수 있습니다. 다시 기록을 재개하려면 일시 중지 시 나오는 옵션 창에서 재개(RESUME)을 선택한 후 왼쪽 하단의 ENTER 버튼을 누름으로써 실행하실 수 있습니다. 또한, 다른 옵션을 선택하려면 오른쪽 버튼 두개를 이용하여 위아래로 이동할 수 있습니다.

주행 기록을 종료하려면 옵션 중 저장(SAVE) 또는 저장안함(DISCARD)를 선택하여 파일로 기록하거나 취소할 수 있습니다.

주행 분석

Micro USB 케이블을 통해 리자인 GPS 기기를 컴퓨터에 연결합니다. 컴퓨터에 표시된 GPS의 Activities 폴더로 들어가시면 .FIT 파일이 생성되었는지 확인하실 수 있으며, 이 파일을 www.lezyne.com/gpsroot 에 업로드하여 저장된 주행 정보를 보거나 공유할 수 있습니다.

더욱 자세한 정보를 보시려면

안전하고 정확한 사용을 위해 리자인에서 제공하는 유저 가이드(메뉴얼)을 꼭 확인해주세요. www.lezyne.com/support-downloads.php에서 .PDF 확장자로 다운로드 받으실 수 있습니다.

메뉴:

- 알림(창)
- 주행 거리
- 주행 시간
- 칼로리
- 최소 심박수
- 최대 심박수
- 스피커
- 타임아웃
- 자동
 - 스크롤
 - 멈춤
 - 구간
 - 라이트(조명)
- 자전거
 - 휠 사이즈
 - 자전거 무게
- 사용자
 - 활동 타임
 - 언어¹
 - 나이¹
 - 체중¹
 - 신장¹
 - 성별¹
- 기록
 - 전체삭제
 - 가장 오래된 기록 삭제
 - 메모리
 - Trip 1 리셋
 - Trip 2 리셋
 - 오도미터 리셋
- 전화
 - 아이폰(iPhone)
 - 안드로이드(Android)
- 네비게이션
 - 경로 재탐색
- 센서
 - 심박수
 - 속도
 - 회전수(Cadence)
 - 속도 & 회전수
 - 파워
 - 기어 변속
- 화면
 - 데이터 페이지
 - ▼ 페이지 번호
 - ▼ 필드 번호
 - ▼ 필드
- 단위 선택
- 백라이트
- 명암
- 알림
- 시간
 - 시간 형식
 - 시각대¹
 - 섬머 타임¹
- 정보
 - 장치
 - 펌웨어
 - GPS
 - 위성
 - HDOP
 - VDOP
 - 건전지
 - FCC ID
 - IC
 - RCM
 - 블루투스 LE
 - Ant+²

1. 필수 항목입니다.
2. GPS 기기가 Ant+를 지원하는 모델인지 확인해주세요.